

Instructions

Flexi Bund

Product Code: 02-1006

STEP 1 Clear the Area

- Clear the area for intended layout of Flexi Bund.

STEP 2 Plan

- Plan the layout of Flexi Bund and pre-cut/trim all pieces to desired length.
- Mark on the concrete, the starting point for each piece.



Step 2

STEP 3 Clean

- Thoroughly sweep and clean the concrete where the Flexi Bund is to be laid, removing all grease, oils and other contaminants.

STEP 4 Apply Adhesive

- Apply a 6 – 8mm bead of adhesive each side of the Flexi Bund lengths running the full length of each piece.
- One tube of adhesive is needed for approx. 3m of Flexi Bund.




Step 4

STEP 5 Lay Each Piece

- Lay each piece immediately following the application of the adhesive at the pre-marked start point on the concrete.
- Press down firmly on the outer edges of the Flexi Bund and wipe away any excess adhesive.

STEP 6 Flexi Bund Corner Sections

- The flap of the Flexi Bund – Corner Section is to overlap the Flexi Bund lengths and adhesive applied as pictured.



Step 6

STEP 7 Allow to Set

- Installed Flexi Bund should be left for 24 hrs to adhere to the floor before being exposed to foot and vehicle traffic.

Alloy Stripping

Installed Flexi Bund can have Alloy Stripping (02-1014) added for extra retention to the concrete in high traffic areas. This may replace the need for adhesive.

The Alloy Stripping is supplied with nylon floor anchors. Use an impact drill with a 6.5mm bit to pre-drill holes in the stripping and 30mm into the floor, before inserting the anchor and either screwing or tapping the expansion nail home.



Alloy Stripping